REASSEMBLY

Reassembly is in the reverse order of disassembly (See page AC-40).

AC1S0-01