REASSEMBLY

Reassembly is in the reverse order of disassembly (See page AC-86).

AC1SQ-01