
AT09C-01

OPERATION



Shift lever position	Gear position	C ₀	C ₁	C ₂	B ₀	B ₂	B ₃	Fo	F ₂
Р	Parking	0						0	
R	Reverse	0		0			0	0	
N	Neutral	0						0	
D	1st	0	0					0	0
	2nd		0			0		0	
	3rd	0	0	0				0	
	O/D		0	0	0				
2	2nd	0	0			0		0	
L	1st	0	0				0	0	0

O: Operating