REASSEMBLY

Reassembly is in the reverse order of disassembly (See page BO-10).

BO1TS-01