REASSEMBLY

Reassembly is in the reverse order of disassembly (See page BO-43).

BO1UC-01