

REMOVAL

1. w/ Roof Rail:
REMOVE ROOF RAIL (See page BO-227)
2. w/ Roof Rack:
REMOVE ROOF RACK (See page BO-228)
3. REMOVE NO.2 ROOF DRIP SIDE FINISH CENTER MOULDING
4. REMOVE ROOF DRIP SIDE FINISH MOULDING

Using a moulding remover, remove the roof drip side finish moulding.

NOTICE:

- Do not damage the body.
- Do not remove the No.2 roof drip side finish moulding clip.
- When the clip comes off, replace it with a new one.

HINT:

Tape the moulding remover tip before use.

