REASSEMBLY

BR0VN-01

Reassembly is in the reverse order of disassembly (See page BR-53). NOTICE:

Apply lithium soap base glycol grease to the parts indicated by the arrows (See page BR-51).