



REASSEMBLY

Reassembly is in the reverse order of disassembly ([See page BR-83](#)).

INSTALL ACCUMULATOR BRACKET

When installing the accumulator bracket, adjust to secure the clearance shown in the illustration on the left.

Standard clearance:

A + B: 4. 1 mm (0. 161 in.) or less

C: 0.3 - 3.8 mm (0.0 12 - 0.150 in.)

HINT:

Secure more than 0.3 mm (0.0 12 in.) clearance for A and B each.