


# THEFT DETERRENT SYSTEM


## HOW TO PROCEED WITH TROUBLESHOOTING

DI01P-07

**HINT:**

Troubleshooting of the theft deterrent system is based on the premise that the door lock control system is operating normally. Accordingly, before troubleshooting the theft deterrent system, first make certain that the door lock control system is operating normally.  
For troubleshooting use a volt/ohm meter.  
Be sure to use troubleshooting procedure appropriate to the diagnostic tool being used.  
Perform troubleshooting in accordance with the procedure on the following page.

Titles inside  are titles of pages in this manual with the page number indicated in the bottom portion. See the indicated pages for detailed explanations.



Step 5, 7 : Diagnostic steps permitting the use of the TOYOTA hand-held tester and TOYOTA break -out-box.