

<b>DTC</b>	<b>23</b>	<b>Vehicle Speed Signal Abnormal</b>
------------	-----------	--------------------------------------

## CIRCUIT DESCRIPTION

See page DI-691.

DTC No.	Detection Item	Trouble Area
23	Vehicle speed sensor pulse is abnormal.	<ul style="list-style-type: none"><li>• Vehicle speed sensor</li><li>• Cruise control ECU</li></ul>

## WIRING DIAGRAM

See page DI-691.

## INSPECTION PROCEDURE

1	Check vehicle speed sensor (See page BE-78).
---	--

NG

Replace vehicle speed sensor.

OK

Check and replace cruise control ECU (See page IN-35).