


ENGINE

HOW TO PROCEED WITH TROUBLESHOOTING

DISOP-01

When using hand-held tester, Troubleshoot in accordance with the procedure on the following page.



When not using hand –held tester, Troubleshoot in accordance with the procedure on the following page.

