ST0AA-02

REASSEMBLY

Reassembly is in the reverse order of disassembly.

(See page \$T-5)

HINT:

At the time of assembly, please refer to the following items.

Use high-temperature grease to lubricate the bearing and gears when assembling the starter.