

# CRUISE MAIN Indicator Light Circuit

## CIRCUIT DESCRIPTION

When the cruise control main switch is turned ON, CRUISE MAIN indicator light lights up.

## INSPECTION PROCEDURE

1	Perform Active Test of hand-held tester.
---	--

**PREPARATION:**

Connect the hand-held tester to the DLC3.

**CHECK:**

Check the cruise indicator of the combination meter using Active Test.

**OK:**

Description	Tester display	Check condition
CRUISE Indicator light	CRUISE INDIC	ON/OFF

OK

Proceed to next circuit inspection shown on problem symptom table (See page DI-865).

NG

Check and replace combination meter.  
(See page IN-38).