

DTC	C1243 / 43, C1245 / 45	Malfunction in Deceleration Sensor
------------	-------------------------------	---

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1243 / 43	While vehicle speed becomes 0 km/h (0 mph) from 30 km/h (18 mph), and the condition that GL1 and GL2 signals of ECU terminals did not change 40 mV or less continued in a sequence 16 times.	<ul style="list-style-type: none"> • Deceleration sensor • Wire harness for deceleration sensor system
C1245 / 45	At the vehicle speed of 30 km/h (18 mph) or more, and the condition that the difference between acceleration and deceleration values of computation from deceleration sensor and vehicle speed becomes more than 0.35 G continues for 60 sec. or more.	

Fail safe function:

If trouble occurs in the deceleration sensor circuit, the ECU cuts off current to the ABS solenoid relay and prohibits ABS & BA & TRC & VSC controls and the brake system becomes normal.

INSPECTION PROCEDURE

HINT:

Start the inspection from step 1 in case of using the hand – held tester and start from step 2 in case of not using the hand – held tester.

1	Check output value of the deceleration sensor.
----------	---

PREPARATION:

- Connect the hand –held tester to the DLC3.
- Turn the ignition switch ON and push the hand –held tester main switch ON.
- Select the DATALIST mode on the hand –held tester.

CHECK:

Check that the deceleration value of the deceleration sensor displayed on the hand –held tester is changing when tilting the vehicle.

OK:

Deceleration value must be changing.

OK

Check and replace ABS & BA & TRC & VSC ECU.

NG

2	Check deceleration sensor (See page DI-4).
----------	---

NG

Replace deceleration sensor.

OK

3

Check for open or short circuit in harness and connector between deceleration sensor and ABS & BA & TRC & VSC ECU ([See page IN-35](#)).

NG

Repair or replace harness or connector.

OK

Check and replace ABS & BA & TRC & VSC ECU.