



Wire Harness Side


Connector "A"




Connector "B"



Connector "C"



Connector "D"



I04189

INSPECTION**1. INSPECT POWER AMPLIFIER CIRCUIT**


Disconnect the connector from power amplifier and inspect the connector on the wire harness side.

Tester connection	Condition	Specified condition
B7 – Ground	Constant	Continuity
C12 – Ground	Ignition switch LOCK and radio switch ON	No voltage
C12 – Ground	Ignition switch ACC or ON and radio switch ON	Battery voltage
B4 – Ground	Constant	Battery voltage


If the circuit is not as specified, inspect the circuits connected to other parts.

Wire Harness Side

Connector "A"



Connector "B"



I04190

2. INSPECT RADIO RECEIVER ASSEMBLY CIRCUIT

Disconnect the connectors from the radio receiver assembly, and inspect the connector on the wire harness side.

Tester connection	Condition	Specified condition
A2 – Ground	Constant	Continuity
A4 – Ground	Constant	Battery voltage
A1 – Ground	Ignition switch LOCK	No voltage
A1 – Ground	Ignition switch ACC or ON	Battery voltage
B4 – Ground	Ignition switch LOCK	No voltage
B4 – Ground	Ignition switch ACC or ON	Battery voltage

If the circuit is not as specified, inspect the circuits connected to other parts.

HINT:

Check the wire harness between radio receiver assembly and the CD auto changer, between radio receiver assembly and power amplifier.