


- (a) Remove the rubber plug from the air flow meter.
- (b) Measure the depth of the idle mixture adjusting screw with vernier calipers.



- (c) Adjust the depth of the idle mixture adjusting screw by turning the screw with SST.  
SST 09243-00020
- (d) Reinstall the rubber plug into the hole of the idle mixture adjusting screw.

## IDLE CO CHECK AND ADJUST (Station Wagon Except Europe)

**HINT:** This check is used only to determine whether or not the idle CO complies with regulations. EGSR6-01

### 1. INITIAL CONDITIONS

- (a) Engine at normal operating temperature
- (b) Air cleaner installed
- (c) All pipes and hoses of air induction system connected
- (d) All accessories switched OFF
- (e) All vacuum lines properly connected
- (f) EFI system wiring connectors fully plugged
- (g) Ignition timing set correctly
- (h) Transmission in neutral position
- (i) Tachometer and CO meter calibrated by hand

### 2. CONNECT TACHOMETER TO ENGINE

Connect the test probe of a tachometer to terminal IG  $\ominus$  of the check connector.


#### NOTICE:

- NEVER allow the tachometer terminal to touch ground as it could result in damage to the igniter and/or ignition coil.
- As some tachometers are not compatible with this ignition system, we recommend that you confirm the compatibility of your unit before use.

### 3. CHECK IDLE SPEED

Idle speed:


$650 \pm 50$  rpm



#### 4. CHECK AND ADJUST CO CONCENTRATION AT IDLE

**NOTICE:** Always use a CO meter when adjusting the idle mixture. It is not necessary to adjust with the idle mixture screw in most vehicles if they are in good condition. If a CO meter is not available, DO NOT ATTEMPT TO ADJUST IDLE MIXTURE.


- (a) Race the engine at 2,500 rpm for approx. 180 seconds.



- (b) Insert a tester probe at least 40 cm (1.3 ft) into the tailpipe.
- (c) Wait at least 1 minute before measuring to allow the concentration to stabilize. Complete the measuring within 3 minutes.


**Idle CO concentration:**

$$1.5 \pm 0.5 \%$$



If the CO concentration does not conform to regulations, adjust by turning the IDLE MIXTURE ADJUSTING SCREW in the variable resistor with SST.

SST 09243-00020



**HINT:** The idle mixture adjusting screw can be tightened through an angle of 260°.

- If the CO concentration is within specification, this adjustment is complete.
- If the CO concentration cannot be corrected by idle mixture adjustment, see the table below for other possible causes.

#### Troubleshooting

CO	Phenomenon	Causes
High	Rough idle (Black smoke from exhaust)	1. Clogged air filter 2. Plugged PCV valve 3. Faulty EFI systems: <ul style="list-style-type: none"> <li>• Faulty pressure regulator</li> <li>• Clogged fuel return line</li> <li>• Defective water temperature sensor</li> <li>• Faulty engine ECU</li> <li>• Faulty injectors</li> <li>• Faulty throttle position sensor</li> <li>• Faulty air flow meter</li> </ul>