



Ts Terminal Circuit

CIRCUIT DESCRIPTION

By connecting terminals Ts and CG of the DLC3, an input signal check can be performed ([See page DI-208](#)).

WIRING DIAGRAM



INSPECTION PROCEDURE**1 Check voltage between terminals Ts and CG of DLC3.****CHECK:**

- (a) Turn the ignition switch ON.
- (b) Measure the voltage between terminals Ts and CG of DLC3.

OK:**Voltage: 9 – 14 V****OK****No problem.****NG****2 Check for open and short circuit in harness and connector between suspension control ECU and DLC3, DLC3 and body ground (See page IN-35).****NG****Repair or replace harness or connector.****OK****Check and replace suspension control ECU.**